

Command table

HEX	ASCII	HEX	ASCII	Function
0x00	0x00	NUL	NUL	NULL Command
0x50	0x57	P	W	[Power]
0x49	0x50	I	P	[Input]
0x52	0x43	R	C	[Remote Code]
0x53	0x55	S	U	[Setup]
0x47	0x54	G	T	[Gamma Table]
0x47	0x53	G	S	[Gamma-bank Switch]
0x47	0x50	G	P	[Gamma Coefficient of Custom 1/2/3]
0x47	0x52	G	R	[Gamma (Red) of Custom1/2/3]
0x47	0x47	G	G	[Gamma (Green) of Custom1/2/3]
0x47	0x42	G	B	[Gamma (Blue) of Custom1/2/3]
0x53	0x43	S	C	[Source]
0x4D	0x44	M	D	[Model]
0x54	0x53	T	S	[Test Pattern]

+      Manufacture Code      +

HEX	ASCII	HEX	ASCII
0x37	0x33	'7'	'3'

HEX	ASCII	HEX	ASCII	Function	Button (Remote controller)	HD350 (RS10)	HD750 (RS20)
0x30	0x31	'0'	'1'	[Up ↑]	○	○	○
0x30	0x32	'0'	'2'	[Down ↓]	○	○	○
0x30	0x33	'0'	'3'	[Back]	○	○	○
0x30	0x34	'0'	'4'	-	○	○	○
0x30	0x35	'0'	'5'	[Power ON]	○	○	○
0x30	0x36	'0'	'6'	[Stand By (Power Off)]	○	○	○
0x30	0x37	'0'	'7'	-	-	-	-
0x30	0x38	'0'	'8'	[Input]	○	○	○
0x30	0x39	'0'	'9'	[Bright]	○	○	○
0x30	0x41	'0'	'A'	[Contrast]	○	○	○
0x30	0x42	'0'	'B'	[RNR(+)]	-	○	○
0x30	0x43	'0'	'C'	[RNR(-)]	-	○	○
0x30	0x44	'0'	'D'	[MNR(+)]	-	○	○
0x30	0x45	'0'	'E'	[MNR(-)]	-	○	○
0x30	0x46	'0'	'F'	[BNR(On)]	-	○	○
0x31	0x30	'1'	'0'	[BNR(Off)]	-	○	○
0x31	0x31	'1'	'1'	[Detail Enhance(+)]	-	○	○
0x31	0x32	'1'	'2'	[Detail Enhance(-)]	-	○	○
0x31	0x33	'1'	'3'	[Quick Alignment]	-	-	○
0x31	0x34	'1'	'4'	[Sharpness]	○	○	○
0x31	0x35	'1'	'5'	[Color]	○	○	○
0x31	0x36	'1'	'6'	[Tint]	○	○	○
0x31	0x37	'1'	'7'	-	-	-	-
0x31	0x38	'1'	'8'	[N.R]	-	-	-
0x31	0x39	'1'	'9'	-	-	-	-
0x31	0x41	'1'	'A'	-	-	-	-
0x31	0x42	'1'	'B'	[Keystone V (+)]	○	○	○
0x31	0x43	'1'	'C'	[Keystone V (-)]	○	○	○
0x31	0x44	'1'	'D'	[Hide]	○	○	○
0x31	0x45	'1'	'E'	-	-	-	-
0x31	0x46	'1'	'F'	-	-	-	-
0x32	0x30	'2'	'0'	[Lens Aperture]	○	○	○
0x32	0x31	'2'	'1'	[Lens Shift (U)]	-	○	○
0x32	0x32	'2'	'2'	[Lens Shift (D)]	-	○	○
0x32	0x33	'2'	'3'	[V-Stretch (On)]	-	○	○
0x32	0x34	'2'	'4'	[V-Stretch (Off)]	-	○	○
0x32	0x35	'2'	'5'	[Aspect (4:3)]	-	○	○
0x32	0x36	'2'	'6'	[Aspect (16:9)]	-	○	○
0x32	0x37	'2'	'7'	[Aspect (Zoom)]	-	○	○
0x32	0x38	'2'	'8'	[Lens Aperture (1)]	-	○	○
0x32	0x39	'2'	'9'	[Lens Aperture (2)]	-	○	○
0x32	0x41	'2'	'A'	[Lens Aperture (3)]	-	○	○
0x32	0x42	'2'	'B'	-	-	-	-
0x32	0x43	'2'	'C'	[Lens Shutter (On)]	-	○	○

0x32	0x44	2'	D'	[Lens Shutter (Off)]	-	○	○
0x32	0x45	2'	E'	[Menu]	○	○	○
0x32	0x46	2'	F'	[OK]	○	○	○
0x32	0x30	2'	0'	[Lens]	○	○	○
0x33	0x31	3'	1'	[Focus (+)]	-	○	○
0x33	0x32	3'	2'	[Focus (-)]	-	○	○
0x33	0x33	3'	3'	-	-	-	-
0x33	0x34	3'	4'	[Right →]	○	○	○
0x33	0x35	3'	5'	[Zoom (T)]	-	○	○
0x33	0x36	3'	6'	[Left ←]	○	○	○
0x33	0x37	3'	7'	[Zoom (W)]	-	○	○
0x33	0x38	3'	8'	[Gamma Normal]	-	○	○
0x33	0x39	3'	9'	[Gamma A]	-	○	○
0x33	0x41	3'	A'	[Gamma B]	-	○	○
0x33	0x42	3'	B'	[Gamma C]	-	○	○
0x33	0x43	3'	C'	[Gamma Custom1]	-	○	○
0x33	0x44	3'	D'	[Gamma Custom2]	-	○	○
0x33	0x45	3'	E'	[Gamma Custom3]	-	○	○
0x33	0x46	3'	F'	-	-	-	-
0x33	0x30	3'	0'	[Keystone_H (+)]	-	○	○
0x34	0x31	4'	1'	[Keystone_H (-)]	-	○	○
0x34	0x32	4'	2'	-	-	-	-
0x34	0x33	4'	3'	[Lens Shift (R)]	-	○	○
0x34	0x34	4'	4'	[Lens Shift (L)]	-	○	○
0x34	0x35	4'	5'	-	-	-	-
0x34	0x36	4'	6'	[Input PC (D-sub)]	-	-	○
0x34	0x37	4'	7'	-	-	-	-
0x34	0x38	4'	8'	-	-	-	-
0x34	0x39	4'	9'	-	-	-	-
0x34	0x41	4'	A'	-	-	-	-
0x34	0x42	4'	B'	[Input Video]	-	○	○
0x34	0x43	4'	C'	[Input S-Video]	-	○	○
0x34	0x44	4'	D'	[Input Component]	-	○	○
0x34	0x45	4'	E'	[Color Temperature 5800K]	-	○	○
0x34	0x46	4'	F'	[Color Temperature 6500K]	-	○	○
0x34	0x30	4'	0'	[Color Temperature 7500K]	-	○	○
0x35	0x31	5'	1'	[Color Temperature 9300K]	-	○	○
0x35	0x32	5'	2'	[Color Temperature HB]	-	○	○
0x35	0x33	5'	3'	[Color Temperature Custom1]	-	○	○
0x35	0x34	5'	4'	[Color Temperature Custom2]	-	○	○
0x35	0x35	5'	5'	[Color Temperature Custom3]	-	○	○
0x35	0x36	5'	6'	[CEC (On)]	-	○	○
0x35	0x37	5'	7'	[CEC (Off)]	-	○	○
0x35	0x38	5'	8'	-	-	-	-
0x35	0x39	5'	9'	[Test]	○	○	○
0x35	0x41	5'	A'	[Double Speed (On)]	-	○	○
0x35	0x42	5'	B'	[Double Speed (Off)]	-	○	○
0x35	0x43	5'	C'	[CTI (Off)]	-	○	○
0x35	0x44	5'	D'	[CTI (Low)]	-	○	○
0x35	0x45	5'	E'	[CTI (Middle)]	-	○	○
0x35	0x46	5'	F'	[CTI (High)]	-	○	○

0x35	0x30	5'	0'	[Color Management (Off)]	-	-	○
0x36	0x31	6'	1'	[Color Management (HDTV)]	-	-	○
0x36	0x32	6'	2'	[Color Management (Film)]	-	-	○
0x36	0x33	6'	3'	[Color Management (Custom	-	-	○
0x36	0x34	6'	4'	[Color Management (Custom	-	-	○
0x36	0x35	6'	5'	[Color Management (Custom	-	-	○
0x36	0x36	6'	6'	-	-	-	○
0x36	0x37	6'	7'	[Game]	○	○	○
0x36	0x38	6'	8'	[Cinema2]	○	○	○
0x36	0x39	6'	9'	[Cinema1]	○	○	○
0x36	0x41	6'	A'	[Natural]	○	○	○
0x36	0x42	6'	B'	[Dynamic]	○	○	○
0x36	0x43	6'	C'	[User1]	○	○	○
0x36	0x44	6'	D'	[User2]	○	○	○
0x36	0x45	6'	E'	[User3]	○	○	○
0x36	0x46	6'	F'	-	-	-	-
0x36	0x30	6'	0'	[Input HDMI 1]	-	○	○
0x37	0x31	7'	1'	[Input HDMI 2]	-	○	○
0x37	0x32	7'	2'	-	-	-	-
0x37	0x33	7'	3'	-	-	-	-
0x37	0x34	7'	4'	[Information]	○	○	○
0x37	0x35	7'	5'	[Gamma]	○	○	○
0x37	0x36	7'	6'	[Color temperture]	○	○	○
0x37	0x37	7'	7'	[Aspect]	○	○	○
0x37	0x38	7'	8'	[Contrast (+)]	-	○	○
0x37	0x39	7'	9'	[Contrast (-)]	-	○	○
0x37	0x41	7'	A'	[Brightness (+)]	-	○	○
0x37	0x42	7'	B'	[Brightness (+)]	-	○	○
0x37	0x43	7'	C'	[Color (+)]	-	○	○
0x37	0x44	7'	D'	[Color (-)]	-	○	○
0x37	0x45	7'	E'	[Sharpness (+)]	-	○	○
0x37	0x46	7'	F'	[Sharpness (+)]	-	○	○