

---

# **USER'S GUIDE**

---

**Model 200 Projector**

---

# DECLARATION OF CONFORMITY

---

PER ISO/IEC GUIDE 22 AND EN 45014

---

**Manufacturer:** Hughes JVC  
2310 Camino Vida Roble  
Carlsbad, Ca 92009  
USA

Hughes-JVC declares that this product conforms to the following Product Specifications (Directive/Standard):

**Safety:** EN 60950/IEC 950 (1992)  
IEC 950 (1992)

**EMC:** EN 55022 (1988) / CISPR-22 (1986) Class "A"  
EN 50082-1 (1992) / IEC 801-2(1991)  
EN 50082-1 (1992) / IEC 801-3(1984)  
EN 50082-1 (1992) / IEC 801-4(1988)

ANSI C63.4-1992, FCC Part 15, Class A

In addition, the above product complies with the requirements of the Low Voltage Directive 73/23 EEC and the EMC Directive 89/336/EEC.

103620 First Edition    December 1995  
103620 Rev A            February 1996  
103620 Rev B            August 1996

## **Confidential and proprietary information.**

© Copyright 1996 by Hughes-JVC Technology Corporation.

All worldwide rights reserved.

This manual was produced by Hughes-JVC Technology Corporation and may be revised without prior notice.

No part of this manual may be reproduced in any form without the express written permission of Hughes-JVC Technology Corporation.

**ILA**<sup>®</sup> is a registered trademark of Hughes-JVC Technology Corporation.

---

# Table of Contents

|  |      |
|--|------|
| <b>Safety Information</b> .....                        | v    |
| <b>Chapter 1 Introduction</b>                          |      |
| 1.1 Shipping and Inspection .....                      | 1-1  |
| 1.2 Items Shipped with the Model 200 .....             | 1-1  |
| 1.3 Options .....                                      | 1-2  |
| 1.4 Projector Control .....                            | 1-2  |
| 1.5 Right and Left Orientation .....                   | 1-2  |
| 1.6 Acronyms Used in Manual .....                      | 1-3  |
| <b>Chapter 2 Installation Parameters</b>               |      |
| 2.1 Physical Dimensions .....                          | 2-1  |
| 2.2 Physical Access and Thermal Clearance .....        | 2-3  |
| <b>Chapter 3 Installation</b>                          |      |
| 3.1 Before Installation-Location Considerations .....  | 3-1  |
| 3.2 Table vs. Ceiling Mounting .....                   | 3-1  |
| 3.3 Projector-to-Screen Alignment .....                | 3-3  |
| 3.4 Lens Throw Distance and Screen Width .....         | 3-4  |
| 3.5 System Connections .....                           | 3-7  |
| 3.6 Video Sources .....                                | 3-8  |
| <b>Chapter 4 Operation</b>                             |      |
| 4.1 Standard Remote .....                              | 4-1  |
| 4.2 Technician Remote .....                            | 4-3  |
| 4.3 Power On Sequence .....                            | 4-6  |
| 4.4 Navigating the Menu .....                          | 4-9  |
| 4.5 Full Menu Structure .....                          | 4-11 |
| 4.6 Selecting a Channel .....                          | 4-13 |
| 4.7 Attaching a Source .....                           | 4-15 |
| 4.8 Picture Settings .....                             | 4-16 |
| 4.9 Menu Item Definitions .....                        | 4-17 |
| 4.10 Short Menu Structure .....                        | 4-21 |
| 4.11 Keyboard/Remotes Command Equivalents .....        | 4-22 |
| <b>Chapter 5 Setup Adjustments</b>                     |      |
| 5.1 Test Patterns .....                                | 5-2  |
| 5.2 Projection Lens Focus (Rough) .....                | 5-3  |
| 5.3 Setup Preparation .....                            | 5-3  |
| 5.4 Timing Settings and Adjustments .....              | 5-9  |
| 5.5 Geometric Adjustments .....                        | 5-11 |
| 5.6 Electronic Focus .....                             | 5-26 |
| 5.7 <b>ILA</b> <sup>®</sup> Sensitivity and Bias ..... | 5-27 |
| 5.8 Convergence .....                                  | 5-28 |
| 5.9 Black Level (G2) and Sensitivity Offset .....      | 5-35 |

---

|                                 |      |
|---------------------------------|------|
| 5.10 Uniformity (Shading) ..... | 5-37 |
| 5.11 Picture Settings.....      | 5-41 |
| 5.12 Backing up Settings .....  | 5-43 |

## **Chapter 6 Maintenance**

|                                  |     |
|----------------------------------|-----|
| 6.1 Preventive Maintenance ..... | 6-1 |
|----------------------------------|-----|

## **Chapter 7 System Specifications**

|                              |     |
|------------------------------|-----|
| Image Quality.....           | 7-1 |
| Input Capability .....       | 7-1 |
| Video Inputs.....            | 7-1 |
| Control Inputs.....          | 7-1 |
| Operating Parameters.....    | 7-2 |
| Installation.....            | 7-2 |
| Accessories (Included).....  | 7-2 |
| Accessories (Optional) ..... | 7-3 |
| Power Plugs.....             | 7-3 |
| Optional Filters.....        | 7-3 |

|   |            |
|---|------------|
| <b>Appendix A, Extron Switcher Interface.....</b> | <b>A-1</b> |
|---|------------|

|  |            |
|--|------------|
| <b>Appendix B, Data Import/Export.....</b> | <b>B-1</b> |
|--|------------|

|                                  |            |
|----------------------------------|------------|
| <b>Appendix C, Glossary.....</b> | <b>C-1</b> |
|----------------------------------|------------|